


# **H·E·R·O**

## **AIRLESS SPRAY EQUIPMENT**

# **300S / 300SL Legend**



**SAFETY, OPERATING AND  
MAINTENANCE INSTRUCTIONS  
AND PARTS LIST**

### **H.E.R.O. Industries**

*a division of Middlefield Bancorp Limited*

**2719 Lake City Way**

**Burnaby, B.C., V5A 2Z6**

**Phone: (604) 420-6543 Toll Free 800-494-4376**

**Fax: (604) 420-8725C**

**E-Mail: [sales@hero.ca](mailto:sales@hero.ca) Website: [//www.hero.ca](http://www.hero.ca)**

## ***H.E.R.O. WARRANTY***

H.E.R.O. INDUSTRIES , guarantees this airless pump to be free of defects in materials and workmanship to the original owner, for a period of one full year from the date of purchase.

The warranty entitles the owner to parts replacement at no charge. The parts replacement warranty is valid for any necessary replacement, whither caused by material or workmanship defect or simple wear. H.E.R.O. Industries offers no warranty on the intake ball, outgo ball, drive belt, hoses, gun or accessories, plastic, rubber, other soft goods or motor used in or supplied with the H.E.R.O. sprayer.

Motor, accessories, etc., which are supplied by other manufacturers and are attached to or supplied with the H.E.R.O. airless pump, are warranted only to the extent that these parts are warranted by their respective manufacturers. Warranty claims must be made directly to such manufacturers or their local authorized service depots.

The warranty is only applicable to the original purchaser and the equipment has been properly used, operated and maintained in accordance with all instructions, precautions and warnings contained in this manual. For the purpose of this warranty, damage resulting from accident, abuse, improper cleaning or operation, fire, flood, or Act of God, is not covered.

H.E.R.O.'s liability is limited to replacing parts found to be defective or worn and does not include; transportation costs, damage or other expenses of any kind incurred in connection with the purchase and use of this sprayer.

Repairs claimed under warranty must be performed at an authorized H. E.R.O. Service Center, using only genuine H.E.R.O. parts. Parts necessary under warranty claim will be supplied by your local H.E.R.O. Service Center.

**DO NOT** return worn parts to factory without authorization.

To qualify for the warranty, the warranty card (attached to this page) supplied with this H.E.R.O. airless pump, must be completed with equipment serial number and signed by the purchaser, and postmarked within ten (10) days of purchase.

## Table of Contents

Important Safety Precautions	4 – 5
Introduction	6
Operating Instructions	6
Setting up to Spray	7
Flushing The Unit	8
Special Notes	9
Airless Spray Painting Suggestions	10 – 13
Trouble Shooting	14 – 22
Intake Seat Replacement	23
Outgo Valve	24
Bleed Valve Repairs	25
Diaphragm Replacement	26
Hydraulic Head Insert Replacement	27
Piston Repairs	28 – 29
Pressure Control Valve Repairs	30
Accessories	31
Parts List & Description	32 – 36
Exploded Unit Schematics	37 – 38

### IMPORTANT

**AS WITH ALL MECHANICAL EQUIPMENT, PROPER OPERATING AND MAINTENANCE PROCEDURES ARE REQUIRED TO KEEP YOUR H.E.R.O. AIRLESS PUMP PERFORMING TO YOUR SATISFACTION. THE FOLLOWING SAFETY, OPERATING AND MAINTENANCE INSTRUCTIONS ARE IMPORTANT.**

Read and understand this manual completely, especially with regard to all safety precautions. Read and follow instructions on all warning labels on your equipment. Keep the warning labels clean and readable at all times. Order new labels from your local distributor or from H.E.R.O. Industries if needed.

The manufacturer shall not be responsible for any loss, damages, or injury of any kind or nature whatsoever resulting from the use the equipment other than in strict compliance with the instructions, cautions and warnings contained in this operating and instruction manual and as displayed on the face of the equipment.

This system is capable of producing 2400 psi. ( spray pressure ). To avoid rupture and injury DO NOT operate this pump with components rated less than 3000 psi. working pressure (including but not limited to spray guns, hose and connections).

Before servicing, cleaning or removing of any part, shut off power and relieve pressure.

# IMPORTANT SAFETY PRECAUTIONS

## WARNING

*Material issuing from the spray tip is at high pressure. If fingers, or any part of the body are placed near the tip of the spray gun, it is possible that the spray could break the skin and inject some of the spray material. If injury does occur, seek immediate attention of a medical doctor. Be prepared to inform the doctor what fluid was injected, if the injury is of an injection nature. Equipment and chemicals when used improperly can be dangerous!*


- ☒ **NEVER** place any part of the body in front of the spray tip or aim the gun toward any part of the body.
- ☒ **NEVER** point the gun toward any individual.
- ☒ **NEVER** treat any injury as a simple cut. If injury does occur, seek immediate medical attention. Be prepared to inform the doctor what fluid was injected.
- ☒ **NEVER** allow another person to use the sprayer unless he is thoroughly instructed on its operation and has read all safety precautions in this manual and all safety warning labels attached to unit.
- ☒ **NEVER** use around children.
- ☒ **NEVER** attempt to perform any maintenance or service on any part of the unit spray system without first;
  1. Shutting off the unit.
  2. Disconnecting the power cord from the outlet.
  3. Relieving all pressure in the pump by triggering the gun.
  4. Locking gun trigger in "LOCKED" position, with gun locked closed.
- ☒ **NEVER** operate the sprayer without the tip guard complete and in place.
- ☒ **NEVER** spray any material in the vicinity of open flame, pilot lights, electrical outlets or any other source of ignition.
- ☒ **NEVER** spray volatile materials with flash points lower than 140 F (60 C).
- ☒ **NEVER** attempt to stop any leakage in the paint line or at any fitting with your hand or any part of your body. Immediately shut off the unit should leakage occur.
- ☒ **NEVER** wash an electric motor, nor operate it in the rain or in wet or damp areas, to protect yourself from electric shock.
- ☒ **NEVER** allow paint hose to become kinked, or to vibrate against rough or sharp surfaces.
- ☒ **NEVER** operate the unit at pressures higher than the pressure rating of the lowest rated component in the system, or at pressure higher than factory preset.
- ☒ **NEVER** spray in an enclosed area. The spraying area must be well ventilated to safely remove chemical vapors.
- ☒ **NEVER** operate the unit with worn or damaged accessories, or with accessories other than those supplied by H.E.R.O. Industries, unless the accessories have been first specifically approved in writing by H.E.R.O. Industries.
- ☒ **NEVER** allow the unit to be serviced or repaired anywhere other than an authorized H.E.R.O. Service Center, or with other than genuine H.E.R.O. parts or components.
- ☒ **NEVER** leave unit unattended without first shutting off, triggering the gun to relieve all pump pressure, and setting the trigger lock on gun in "LOCKED" position, with gun locked closed.

## ALWAYS

- ☑ **ALWAYS** follow H.E.R.O. recommendations for operation and safety completely.
- ☑ **ALWAYS** ensure that switch is in off position before plugging in the electric motor.
- ☑ **ALWAYS** set trigger lock on gun in "LOCKED" position when not in use, with gun locked close.
- ☑ **ALWAYS** check connections and fittings for tightness before operating the unit.
- ☑ **ALWAYS** locate the unit in a well ventilated area a minimum of 25 feet from the spray area.
- ☑ **ALWAYS** ground the unit, the paint containers, and the object being sprayed to eliminate static discharge. Ensure that all these objects remain grounded throughout the entire spraying operation.
- ☑ **ALWAYS** use approved 3 prong grounded extension cord and approved grounded outlets of the voltage and frequency specified on the motor. The outlet must be at least 25 feet from the spraying area.
- ☑ **ALWAYS** use approved 3 prong grounded extension cord not less than # 12/3 gauge up to 50 feet, and not less than # 10/3 gauge up to 100 feet. **DO NOT** exceed 100 feet of extension cord.
- ☑ **ALWAYS** use accessories and components approved for at least 3000 psi (working pressure) in the spraying system.
- ☑ **ALWAYS** use accessories and components supplied by H.E.R.O. Industries, or specifically approved in writing by H.E.R.O. Industries on with the unit
- ☑ **ALWAYS** examine accessories for wear or damage before operating the unit
- ☑ **ALWAYS** use lowest possible pressure when flushing and cleaning the unit, and hold the gun firmly against a metal container to reduce static discharge possibility.
- ☑ **ALWAYS** wear a face filter mask when operating the unit.
- ☑ **ALWAYS ;**
  1. Turn off the motor
  2. Disconnect the power cord from the outlet.
  3. Relieve all pressure in the pump by triggering the gun.
  4. Lock gun trigger in "**LOCKED**" position, with gun locked closed before attempting to perform any maintenance or service on any part of the unit spray system.
- ☑ **ALWAYS** wear safety glasses when operating the unit.
- ☑ **ALWAYS** ensure fire extinguishing equipment is readily available and properly maintained in the spray area.
- ☑ **ALWAYS** observe good housekeeping and keep the spray area free from obstructions.
- ☑ **ALWAYS** be aware that certain chemicals may react with aluminum, carbide, or other components in the pump system. Read the manufacturer's label on all materials to be sprayed, and follow the manufacturer's recommendations. If in doubt, consult your material supplier to be sure.

# H.E.R.O. AIRLESS SPRAY PAINTING

Welcome to the world of H.E.R.O. airless paint spraying. We are sure you will enjoy owning and operating your new H.E.R.O. model 300S or 300SL. With H.E.R.O. airless spray equipment you will avoid the inconvenience and mess of over spray. You are spraying paint, not air, and the paint is driven to the painting surface in a clean, fan shaped spray which penetrates all cracks and corners. To attain these results, you must adjust the pressure as low as possible. We recommend that you become familiar with your H.E.R.O. unit. Discuss with your dealer the useful accessory items he has to offer - various types of tips, extension poles for hard to reach areas, extra hose, etc. Use of accessory items is often the difference between a good job and an excellent one!



## OPERATING INSTRUCTIONS

### WARNING

Do not attempt to operate this machine until you have read and understood all safety precautions and operating instructions. Equipment and chemicals when used improperly can be dangerous.

Your H.E.R.O. airless sprayer has been fully factory tested prior to shipment.

### BEFORE STARTING YOUR H.E.R.O. PUMP....

**CHECK** to ensure that the shipping seal has been removed from under the cap on the hydraulic tank. Hydraulic tank should be at least 3/4 full of H.E.R.O. LVO hydraulic fluid.

**CHECK** all fittings and connections in the pump system, hose, and gun to ensure that they are tight.

**CHECK** to ensure that there is a spray tip in the gun, and that the tip is the correct size for the coating you are to spray. ( There are various tips available, for each type of coating or configuration. See " Airless Spray Tip " on page 12/13 , for proper tip selection.





**CHECK** to ensure that you have H.E.R.O. strainer bags, H.E.R.O. Wonder Wash, appropriate thinner for the paint, a waste container, and any other accessories you may require for the job.

**CHECK** to ensure that you have adequate extension cord size and length if the machine cannot be situated immediately next to an electric outlet. Distances up to **50 feet** require #12/3 wire grounded cord, up to **100 feet** require #10/3 wire grounded cord. **DO NOT exceed 100 feet of extension cord.** If distance is greater, obtain and install extra length of H.E.R.O. airless spray hose.

**READ THIS MANUAL THOROUGHLY.**

## SETTING UP TO SPRAY

- 1 Remove unit from shipping carton. Inspect exterior of unit for any signs of freight damage. If any parts are found to be broken or damaged, immediately contact the carrier and arrange for an inspection of the concealed damage. Claims for freight damage **must** be made by the **CONSIGNEE** and not by the shipper. The carrier accepts full responsibility for the safe delivery of merchandise upon pick-up from the shipper.
- 2 Attach intake hose assembly (ref# 1) onto hose barb (ref# 7). Tighten clamp (ref# 6 ) securely.
- 3 Attach prime hose (ref# 48) to prime valve (ref# 44). Secure with clamp (ref# 49).
- 4 Attach paint hose to outgo tee (ref# 33).
- 5 Attach gun to paint hose. **NOTE; Spray tip and tip guard should be attached to gun prior to attaching to hose.**
- 6 Place intake siphon assembly into a clean 5 gallon pail.
- 7 Install strainer bag (accessory item 5GAL SB) in pail and secure with large rubber band ( accessory item 106). **NOTE; Strainer bag must remain 4 inches from the bottom of pail**
- 8 Trigger gun to release any pressure in the unit. Use extreme caution to ensure that the gun is not directed towards anyone or any object which may be damaged. **NOTE; Unit may contain storage solution.**
- 9 To remove storage solution, add one gallon of thinner, compatible with the type of paint to be used, to the siphon pail.
- 10 Turn pressure control handle (ref# 43) counter clockwise to lowest pressure setting.
- 11 Be sure motor switch is in "OFF" position. Plug unit into 115V, 15 amp., grounded circuit. **NOTE; If using an extension cord, you MUST use a #12/3 wire grounded cord, up to 50 feet or #10/3 wire grounded cord, up to 100 feet. DO NOT EXCEED 100 FEET OF EXTENSION CORD. If distance is greater, purchase and install additional lengths of airless spray hose.**
- 12 Turn motor switch "on".
- 13 Turn prime valve handle (ref# 43) counter clockwise until fully open. Allow thinner to circulate back into the siphon pail for a few minutes. Then turn the prime valve knob clockwise to close the valve ( close tightly ), and direct the flow to the paint hose and gun. Leave the pressure setting low.
- 14 Trigger gun into waste container.
- 15 Pour paint through strainer bag into siphon pail.
- 16 Repeat steps 13 and 14, until paint flows freely. **NOTE; Never turn prime valve back to "prime" position when the unit is under pressure.**
- 17 Spray a test pattern. Begin by spraying a test pattern onto old newspaper or other scrap material.
- 18 Increase the pressure, slowly at first, by turning the pressure control knob clockwise. Continue increasing the pressure until the spray pattern is uniformed from top to bottom, with no heavy areas. Secure pressure control setting, by turning the silver lock ring (ref# 76) counter clockwise until snugly against the face of the pressure control knob. If heavy areas are still visible at maximum pressure setting, thin the paint with the correct thinner, according to the paint manufacturer's recommendations.



## FLUSHING THE UNIT AT SHUTDOWN OR COLOR CHANGE





*If shutting down for a short period of time, it is sufficient to trigger the gun to relieve pressure. Then set the safety lock on gun to "locked" position with the gun locked closed and immerse the gun in a container of the correct thinner for the paint you are spraying.*

1. Remove spray tip from gun.
2. Turn pressure control knob counter clockwise to low pressure setting. Only use sufficient pressure to allow material to move through the sprayer. **DO NOT** operate at or near full pressure.
3. Remove siphon assembly from paint container.
4. Trigger gun, back into paint container, until unit runs dry.  
**NOTE:** Pump and spray hose will continue to contain paint. This paint may be recovered by placing prime hose into paint container and draining the remainder while re-priming with cleaning fluid. See step 5\* and 6\*.
5. Place siphon assembly in container of correct thinner, for the spray product being used,, and prime the pump as shown in step 13, of "Spraying". \*See special notes from step 4. Allow thinner to circulate back into the container for a few minutes to flush the prime valve.
6. Close prime valve.
7. Trigger gun into paint container until thinner comes through. \*See special notes from step 4. Re-direct flow into waste container and continue spraying until thinner runs clear. Heavily soiled thinners may have to be changed to complete cleaning job.
8. Lift siphon assembly and allow pump to run dry.
9. Repeat procedure using a gallon of **H.E.R.O. Equipment Wonder Wash** solution. If not using Wonder Wash, unit **must not** be stored with water. Only store with a non corrosive material ( Paint thinner, solvent ).
10. Switch unit "off" and trigger gun to relieve remaining pressure.
11. Remove and rinse gun handle filter in correct thinner.

### SPECIAL STORAGE INSTRUCTIONS

In areas where the sprayer is **NOT** used 12 months of the year, special preparations must be used for winter or off season storage. Because solvents evaporate quickly, they should not be used for long term storage. A petroleum based solution ( solvent and oil ) should be used as an extended storage material. **DO NOT** allow storage solution to freeze in the sprayer.

*H.E.R.O. Equipment Wonder Wash, available from your H.E.R.O. distributor, will provide the added cleaning benefits of solvent at a much lower cost. Suitable as a short term ( 1-2 days ) storage solution only*



## SPECIAL NOTES AND INSTRUCTIONS

**NEVER LEAVE THE UNIT UNDER PRESSURE WHEN NOT SPRAYING (MOTOR TURNED OFF). RELIEVE PRESSURE BY TRIGGERING GUN. NEVER STORE THE UNIT WITH PAINT OR WATER IN THE PUMP SYSTEM, EVEN OVERNIGHT.**

- ☒ NEVER attempt to start the motor when the unit is under pressure. Relieve pressure and follow instructions in "Setting up to spray"
- ☒ NEVER attempt to run the motor on longer or lighter extension cord than specified.
- ☒ Avoid operating the unit while tilted. Keeping it level assures greater operating efficiency.
- ☑ If motor's thermal overload switch has opened, unplug unit and allow it to cool.
- ☒ **DO NOT** attempt to resume spraying before determining and correcting the cause of overheating.
- ☑ Always follow flushing and cleaning instructions exactly.
- ☑ In hot weather, locate unit in shade.
- ☑ Regularly check the level of H.E.R.O. LVO hydraulic fluid in the hydraulic tank. It should be kept near full, top up as needed with only genuine H.E.R.O. LVO hydraulic fluid.
- ☑ Crankshaft eccentric bearing should be greased at regular intervals consistent with hours of use. Use MO-2 grease ( i.e. common auto grease) approximately every 10 hours of operation.
- ☑ If you wish to power your H.E.R.O. airless sprayer with a generator, it must be a minimum of a **4500** watt generator, in good operating condition.  
**NOTE;** An electric tool must be powered by a generator which has an output wattage of at least three times the maximum draw of the motor under full load.
- ☑ A minimum 50' and a maximum of 300' of airless spray hose may be used.  
**NOTE:** 50' x 3/8" paint hose ( part # 117 ) should be used for every 50' x 1/4" paint hose ( part # 114 ) over 100'.  
100' total length of paint hose = 2 of 50' x 1/4" paint hose.  
150' total length of paint hose = 2 of 50' x 1/4" paint hose and 1 of 50' x 3/8 paint hose.  
200' total length of paint hose = 2 of 50' x 1/4" paint hose and 2 of 50' x 3/8 paint hose.  
250' total length of paint hose = 3 of 50' x 1/4" paint hose and 2 of 50' x 3/8 paint hose.  
300' total length of paint hose = 3 of 50' x 1/4" paint hose and 3 of 50' x 3/8 paint hose.
- ☑ Product viscosity, altitude ( feet above sea level ) and vertical reach can effect pump performance and special accessories may be required. Product viscosity may have to be further reduced at higher elevations. Special " High Altitude" siphon assemblies ( part # 4210-HA ) are available for use in areas at or above 5000 feet above sea level. This kit may also prove beneficial if spraying thicker viscosity materials. The larger diameter 3/8" paint hose should also be used.
- ☑ Check drive belt ( part # 66/100 ) tension frequently. The belt will stretch with use, and should be adjusted after 20 hours of operation and again after 50 hours. Periodic checks after 50 hours should be made. Failure of the drive belt is not covered by the equipment warranty, so proper maintenance of the belt is important.
- ☑ Regularly check fittings, bolts, nuts and connections for damage. Tighten, adjust or replace as required.
- ☑ Check crankshaft alignment often. An out of alignment crankshaft will cause the damage to the eccentric bearing.

# **AIRLESS SPRAY PAINTING SUGGESTIONS AND TECHNIQUE**

A good airless spray application is the result of many factors. Surface preparation, which includes cleaning and degreasing, priming, material compatibility, quality finish product and correct application technique, are all important to the finished results.

The key to all good applications is a good spray gun technique. The finished results are what the client will look at and base his opinion on. Your skill and abilities are as important as good equipment and good paint. Proper application techniques can easily be learned by using the following simple guidelines. If you are not familiar with the basic spray techniques we recommend that you study this portion of the manual and practice the techniques shown. Practice your technique on scrap cardboard or old newspaper until you feel confident.

## **FOR EXCELLENT RESULTS, READ AND PRACTICE THESE TECHNIQUES**

1. Always strain all paint through a H.E.R.O. strainer bag.  
The most common reason for airless sprayers to malfunction is foreign matter jamming the valves or plugging the tip. Always strain the paint before putting through the pump.
2. Always spray at the lowest pressure setting which will provide a uniform spray fan. (fig. 1, page 11)  
Adjust pressure control knob so that paint is completely atomized . Insufficient pressure will result in "tailing". Too much pressure will result in excess fog and over spray, excess tip wear, and increased sprayer wear and tear. See setting up to spray, page 5.
3. Always spray at right angles to the surface being sprayed. (fig. 2, page 11)  
Angling or arcing the nozzle toward the surface will cause uneven coverage and excessive over spray.
4. Always hold spray gun 12-15 inches from spray surface. (fig. 3, page 11)  
Too close and the fan width will be reduced and material will be applied too heavily (runs).  
Too far from the surface and you will have excessive over spray and light coverage (transparent).
5. Always move the gun parallel to the surface being sprayed, at a consistent speed.  
This avoids uneven coverage (thick or thin areas).
6. Always start the spray stroke before triggering the gun and release the trigger before completing the stroke. (fig. 4, page 11)  
This avoids heavy build up of paint at either end of the spray stroke.
7. Always lap your spray pattern by one half. (fig. 5, page 11)  
This assures full coverage of the surface being painted.

# AIRLESS SPRAY PAINTING SUGGESTIONS AND TECHNIQUE

FIG. 1





FIG. 2




FIG. 2

FIG. 3






FIG. 4

FIG. 5

# AIRLESS SPRAY PAINTING SUGGESTIONS AND TECHNIQUE

## SPRAY TIP SELECTION

TIP SIZE	FOR APPLICATION OF
.021	Exterior Latex on large unobstructed areas. (max. size allowed) ( 60 OZ. )
.018	Interior Latex, Exterior Latex, Shake Paint, Exterior Flat Paints. ( 46 OZ. )
.015	Alkyd Flat Enamel, Interior Latex, Semi-Gloss Enamel, Stains. ( 30 OZ. )
.013	Fine ground Gloss Enamels, and good quality Stains. ( 23 OZ. )
.011	Clear Varnishes and Lacquers. ( 15 OZ. )
.009	Clear Varnishes and Lacquers. ( 10 OZ. )

**NOTE:** *The above volumes achieved with gun wide open for 1 minute and pump spraying at 2000 psi. All volumes are approximate. To test worn tips, spray water through the tip at 2000 psi. for 1 minute. Spray into bucket and weigh amount (less weight of bucket). If it is substantially greater than what is listed above, then the tip should be discarded or reclassified. As a tip wears, the hole gets larger and the fan pattern becomes narrower.*

### ORIFICE SIZE

All tips are rated by the size of the orifice or bore size. The bore size is measured in thousandths of an inch ( .018 = 18 thousandths of an inch ). The size of tip required is based on the consistency of the material to be sprayed. The thicker the paint, the larger the tip size required. Always consult the product label or ask the paint retailer for the manufacturer's recommendations with regard to proper tip sizes.

### FAN WIDTH

Fan width or pattern width is determined by the spray tip's "fan width" classification. This size is measured in inches, and is determined when spraying 12 inches from the spray surface. Various methods of noting the fan widths are used by tip manufacturers. Ask your distributor for assistance.

**NOTE:** *Two tips having the same tip size, but different fan widths will deliver the same amount of paint over a different area (wider or narrower strip). A spray tip with a narrow pattern width makes it easy to spray in tight places. Use only good quality, high-pressure tungsten carbide spray tips.*

### SPRAY TIP REPLACEMENT

During use, especially with Latex paint, high pressure and material abrasion will cause the orifice to grow larger. As the orifice grows larger, the fan width grows smaller. Replace tips before they become excessively worn. Worn tips waste paint, cause over spray, make cutting in difficult, and decrease sprayer performance.

**NOTE:** *When using Latex paint, a spray tip will wear at the rate of one size for approximately every 100 gallons of material sprayed.*

*An excessively worn tip can be the cause of apparent operating problems with the unit. If a tip is worn past the aperture size which the unit can support, pulsation will become evident in the spray fan/pattern. Added strain is placed on the Hydrapulse membrane as it attempts to keep the spray pressure consistent. When the tip wears beyond .021, it is releasing more material than the unit is bringing in. The natural reserve of product in the paint chamber is reduced and harm to the membrane begins. ALWAYS check your tips for wear when trouble shooting the equipment. The 300S/SL can support up to a maximum of a .021 tip.*

# SPRAY TIP SELECTION

## AIRLESS TIP'S FLOW RATE ( GALLONS PER MINUTE )

Orifice Size In Inches	GPM Flow Rate	Orifice Size In Inches	GPM Flow Rate
.007	.05	.018	.35
.009	.08	.019	.40
.011	.12	.021	.47
.013	.18	.023	.57
.015	.23	.026	.72
.017	.30	.031	1.1

## AIRLESS TIP RECOMMENDATIONS

COATINGS	COATING VISCOSITY	FILTER MESH	ORIFICE SIZE *
Varnishes	Light Body	100 – 150	.009, .011
Lacquer Finishes (clear)			.009, .011
Sanding Sealers			.009, .011
Shellac (clear)			.009, .011
Transparent Stain			.011, .013
Water Sealers (clear)			.011, .013
Solid Stains	Medium Body	60 – 100	.013, .015
Exterior House Paint			.013, .017
Interior Wall Paint			.015, .017
Interior & Exterior Primers			.017, .019
Commercial Grade Architectural Coatings:			
Interior Wall Paints	Heavy Body	30 – 60	.017, .019
Interior Wall Primers			.017, .019
Dry Fall (Quick Dry)			.019, .023
One Coat, Primer-Finish Paints			.019, .023
Elastomerics	Extra Heavy		.021 – .031
Pigmented Water Proofer's			.021 – .027
Block Filler			.025 – .031

\* Fan width between 8 and 12 inches.

# TROUBLESHOOTING


**Hydraulic Energy Regulated Output (H.E.R.O.)** is more than just our name, it is the bases for the operation of the pump. It is the regulation or control, of hydraulic energy, which allows the equipment to build and then deliver or have an output of pressure. Once you have a basic understanding of the operation of the equipment and the effect created in one area and how it will effect operation in another area, you will be better able to diagnose and make repairs.

All H.E.R.O. diaphragm pumps are made up of two (2) distinct pumps. The first, and most important pump is the hydraulic pump. The hydraulic system is made up of two valves, the hydraulic intake valve (ref# 62) and the hydraulic outgo valve, known as the hydraulic pressure control valve (ref# 73). The second pump is known as the paint or material pump. The paint system is made up of two basic valves, the paint intake valve assembly (ref# 11-15), paint outgo valve, (ref# 22). A third valve, known as a prime valve (ref# 34) is used during the priming procedure, (see "setting up to spray"). For correct operation, all five valves must be in good working condition. For this manual we will refer to the two systems as "hydraulic" and "paint". At the center of these two pumps is the diaphragm. The diaphragm is a flexible nylon disc which transfers the energy (pressure) created by the hydraulic pump, to create energy (pressure) in the paint pump. The function of the diaphragm is to create a barrier between the hydraulic oil and the spray material and transfer the energy created.

To fully understand and trouble shoot a H.E.R.O. pump, always keep in mind that "for every action, there is an opposite or corresponding re-action". For every action of the hydraulic intake valve (ref# 62), there is an opposite re-action of the hydraulic outgo valve (ref# 73). At the same time there are corresponding re-actions taking place within the paint pump. This means that as the hydraulic intake valve is opening, so is the corresponding paint intake valve, and while the hydraulic outgo valve is closing, so is the corresponding paint outgo valve. The operation and function of each valve is discussed at the end of this section.

For correct operation to begin, the hydraulic system must be fully primed and all air must be removed ( see "**purging**" page 19 ). Operation begins with piston in the backward position (fig.# 2). At this point the hydraulic intake is open, while the hydraulic outgo valve is closed. The corresponding paint valves are in similar positions.

As the piston moves forward, it pushes hydraulic oil forward. This movement of oil causes the hydraulic intake valve to close and the diaphragm to move forward (fig.# 1). The hydraulic outgo valve will remain closed until sufficient pressure is created to cause it to open. While the hydraulic valves are operating a corresponding re-action is taking place in the paint valves. The forward movement of the diaphragm pushes the paint, causing the paint intake valve, (ref# 11-15) to close. The trapped paint requires a means of release, so it forces the outgo valve, (ref# 22), to open and paint flows to the gun.



## **TROUBLESHOOTING**

The backward movement of the piston, creates a vacuum in the hydraulic system. This causes the hydraulic outgo valve to close and the hydraulic intake valve to open (fig# 1). Opening of the hydraulic intake valve allows a new supply of hydraulic oil to enter the system, replacing the oil which was used on the forward stroke. Once again a corresponding re-action is taking place in the paint pump. The diaphragm is pushed backward by the paint intake spring, (ref# 15). The backward diaphragm movement causes a vacuum in the paint pump. This vacuum causes the intake valve to open, allowing a new supply of paint to enter. The corresponding paint outgo valve is drawn closed by the vacuum created by the diaphragm.

These operations are repeated at a rate of 750 times a minute. These continuously repeated actions draw paint into the pump, pressurize it, and then deliver it to the gun. The failure, of any one valve, to operate correctly will effect the overall equipment performance.

Each of the five valves mentioned earlier, have an important function and will effect the overall performance of the unit if not performing correctly.

### **HYDRAULIC INTAKE VALVE (REF# 62, PART # 4-30)**

The hydraulic intake valve, is a small vacuum valve which controls the hydraulic oil entering the hydraulic pump/cylinder area. Once the oil has past through the valve it is prevented from returning. The valve is commonly called a "one way check valve". Valve failure will result in the hydraulic pump being unable to build pressure, and the diaphragm will stop moving. Spray pressure will cease.

### **HYDRAULIC OUTGO VALVE (REF# 73, PART # 4-27C)**

The hydraulic outgo valve, better known as the "pressure control valve", is used to control the units operating pressure. The valve is fully adjustable from 0 psi. to 3000 psi. By turning the pressure control valve knob (ref# 74) clockwise the pressure is increased. The hydraulic pump continues to build at all times and must have a means of releasing this pressure. Pressure applied to the P.C. ball, (ref# 87) will keep it lodged in the P.C. seat (ref# 86) until the internal hydraulic oil pressure is sufficient to cause it to open. The point at which the oil is released is equal to the level set by the control knob. As components within the pressure control valve wear, the valve loses its ability to maintain or reach the required pressures (see "low static pressure").

### **PAINT INTAKE VALVE ASSEMBLY (REF# 11-15)**

The paint intake valve is made up of five items, endcap (ref# 11) complete with seat (ref# 12), intake ball (ref# 13), cage complete with spring (ref# 14), and large spring (ref# 15). The intake valve controls the incoming flow of spray materials and is responsible for keeping them from returning to the source. The ball must be able to create a complete seal on the seat, otherwise pressure will be lost. A worn intake valve will permit correct static pressure, but supply lower spray pressure. A worn intake ball will become smaller in diameter and lose its ability to seal at the seat. A worn seat will develop a large step in the area where contact with the ball is made. This can cause the intake ball to distort in shape making the ball egg shaped. If the valve assembly becomes warm to the touch, this may be a sign of a loose or worn seat or erosion / wash out of the endcap block. The seat is Loc-Tited into the endcap and must remain tightly sealed at all times.

# TROUBLESHOOTING

## PAINT OUTGO VALVE (REF# 22, PART # 4-11A)

The paint outgo valve monitors and controls the flow of spray materials as it leaves the sprayer. It also works together with the paint intake valve, to build paint pressure as specified by the setting made by the hydraulic outgo valve (pressure control valve). A worn outgo valve will result in pulsation in the spray material and cause the paint hose to jump and vibrate vigorously.

## PRIME VALVE (REF# 34, PART # 4-606 – NEW)

The prime valve is used at the beginning and end of the spray operation (see "setting up to spray"). The function of the prime valve is to assist in removing air from the paint pump when beginning to spray. It is necessary to remove all air from the paint pump so that the spray material can replace it. The pump will function without the prime valve, however, the initial priming procedure would require considerably longer to complete. During the priming procedure the diaphragm is exposed to its greatest amount of stress. Use of the prime valve and a lightweight thinner, which is compatible with the intended spray material, will reduce diaphragm stress and reduce priming time. The prime valve will also allow you to remove any unused paint left in the pump and hose at the completion of a job. When the prime valve is open the material is pumped through the paint intake and outgo and back to the source by way of the prime valve return hose. When closed, no material should be escaping from the prime valve return hose (ref# 48). If material escapes through the prime valve return hose, when the valve is closed, spray pressure at the gun will be reduced.

*The solution to almost all problems can usually be found in the paint side valves. However, before performing any repair or looking further, the following are things which can cause an apparent sprayer failure, without any mechanical problem. ALWAYS check these items before proceeding.*

1. Circuit breaker open or fuse blown.
2. Motor not plugged in.
3. Motor not switched on.
4. Motor thermal reset popped.
5. Too light or too long of an extension cord.
6. Pressure control knob loose or missing.
7. Spray tip plugged.
8. Spray tip worn out.
9. Gun handle filter plugged.
10. Paint hose plugged.
11. Loose fitting or hole in siphon hose.
12. Intake siphon hose plugged.
13. Siphon screen missing or plugged.
14. Sprayer under pressure when restarting.
15. Strainer bag plugging siphon screen.

**UNLESS YOU ARE KNOWLEDGEABLE ABOUT THE REPAIR OF HIGH PRESSURE EQUIPMENT, DO NOT ATTEMPT TO REPAIR AN AIRLESS SPRAYER YOURSELF. ALWAYS FOLLOW ALL SAFETY PRECAUTIONS. THE H.E.R.O. SERVICE VIDEO TAPE (1-620-VHS OR 1-620-BETA) WILL PROVIDE COMPLETE SERVICE TRAINING. SEE YOUR H.E.R.O. DISTRIBUTOR TO PURCHASE A COPY.**

# TROUBLESHOOTING

## PRESSURE TEST

To verify the performance of an airless sprayer, use of pressure gauge is required. A pressure gauge (min. 3000 psi) installed at the gun, using a new .021 tip, and not less than 50 feet of H.E.R.O. airless spray hose is needed. If you do not have access to these items, your local H.E.R.O. authorized service center will be able to perform this test. Your model 300S/SL is manufactured to perform at;

- 2650 psi -- Static pressure, with lock ring (ref# 76) on pressure control valve (ref# 73).
- 1950 psi -- Pressure drop, when gun trigger is squeezed.
- 2250 psi -- Spraying pressure, after recovery time.



If your unit is unable to perform to the above pressure levels consult the troubleshooting guide for the required repair procedure.

## DIAPHRAGM TEST

If your unit is disabled and you are unable to perform a pressure test, use the following procedures for determining the area to repair. This test will divide the two halves of the equipment (hydraulic from paint) and make identification of your solution easier to obtain. This test is commonly referred to as the "Diaphragm Test"

The solution to almost all problems can be found in the paint side valves, due to the increased wear from contact with the abrasive paint/spray materials. Intake valve assembly (ref# 11-15), Outgo valve (ref# 22), and Prime valve (ref# 34) make up the three paint valves. Refer to pages where exploded views of these valves are shown. To eliminate the hydraulic side of the pump (piston side of diaphragm) as a source of problems;

- 1 Remove the intake valve end cap (ref# 11) by removing the four cap screws (ref# 9 ).
- 2 Remove large spring (ref# 15).
- 3 Start unit.
- 4 Increase the pressure by turning the pressure control knob (ref# 74) clockwise to full pressure.
- 5 Put pressure on the center of the exposed diaphragm with the handle of a screwdriver or other blunt object. **NOTE: The diaphragm is located between the paint head (ref# 18) and the hydraulic head (ref# 53)**
- 6 If you are **UNABLE** to stop or alter the hydropulse membrane's movement, then the hydraulic side is operating properly. The problem is located in the "Paint" pump. See troubleshooting guide for additional information.



# TROUBLESHOOTING

## ***SITUATION***

### **POSSIBLE CAUSE (REMEDY)**

#### ***ELECTRIC MOTOR WON'T START/RUN***

1. Unit unplugged or building circuit fuse is blown. (check, replace or reset fuse)
2. Pump under pressure. (reduce pressure setting by turning pressure control knob counter-clockwise, trigger gun to relieve pressure).
3. Too light or too long of extension cord. (replace with correct cord. If distance greater than 100 feet, obtain and install extra length of H.E.R.O. airless spray hose).
4. Unit's thermal overload switch has opened. (determine and correct cause of overheating).

#### ***ELECTRIC MOTOR STALLS/QUITS***

1. See "Electric Motor Won't Start/Run"
2. Drive belt is loose. (tighten drive belts by evenly turning belt tension bolts on either side of motor clockwise. Loose belts generally emit loud squealing noises).
3. Unit primes, builds pressure, but pump "seizes" or "stops" when gun is triggered. ( loose belts, tighten).

#### ***TOTAL LOSS OF PRESSURE, DIAPHRAGM MOVEMENT CANNOT BE STOPPED OR ALTERED. (SEE "DIAPHRAGM TEST")***

1. Paint too thick. (thin paint according to manufacturer's recommendations).
2. Intake ball (ref# 13) worn or jammed opened/closed. (remove intake endcap (ref# 11) and cage (ref# 14). Inspect intake ball, (ref# 13), to ensure it is free, round, and has no nicks or cuts. Inspect ball cage and cage spring for damage or wear. Inspect for foreign material jamming ball. Replace parts as needed).
3. Intake seat loose/bypassing. (remove intake endcap, (ref# 11) and ball cage, (ref# 14). Check seat to ensure it is tightly secured in endcap block. Remove intake elbow (ref# 8) and inspect block from the inbound direction. Look for any washout or erosion. Removal of seat may be required for positive identification of washout or erosion).
4. Outgo valve ball (ref# 26) worn or jammed. (remove outgo valve, (ref# 22). Invert valve and unthread outgo valve upper, (ref# 29), from outgo lower, (ref# 23). Remove crush washer, (ref# 24), outgo seat, (ref# 25), outgo ball, (ref# 26), outgo cage, (ref# 27), outgo spring, (ref# 28), from outgo upper tunnel. Inspect outgo ball to ensure that it is round and free of nicks or cuts. Inspect for foreign material jamming ball. Inspect ball and cage for wear. Replace parts as needed).
5. Outgo valve (ref# 22) incorrectly assembled. (disassemble and reassemble outgo valve, closely following detailed instructions on page 24).

#### ***TOTAL LOSS OF PRESSURE, DIAPHRAGM HAS NO MOVEMENT OR MOVEMENT CAN BE STOPPED. (SEE "DIAPHRAGM TEST")***

1. Hydraulic intake valve (ref# 62) defective. (remove hydraulic feed line, (ref# 63), from hydraulic intake valve. Plug hydraulic feed line so hydraulic fluid does not drain. Remove hydraulic intake valve from elbow, (ref# 61). Check hydraulic intake valve to ensure that it flows in one way only, into the cylinder. Replace if necessary. **NOTE;** Item cannot be repaired ).

# TROUBLESHOOTING

## **SITUATION**

### **POSSIBLE CAUSE (REMEDY)**

#### **TOTAL LOSS OF PRESSURE, DIAPHRAGM HAS NO MOVEMENT OR MOVEMENT CAN BE STOPPED...CONTINUED.**

2. Air lock created on hydraulic side of pump. (air entering hydraulic side due to loose hydraulic feed line fittings, (ref# 63), punctured hydraulic feed line, poor seal at hydraulic intake valve, (ref# 62), or elbow, (ref# 61). Tighten hydraulic feed line, test for leaks, or apply Teflon tape or pipe sealant on fittings. Purge air as per detailed instructions below).
3. Pressure control valve ball (ref# 87) worn out/jammed. (remove hydraulic return line, (ref# 72), from pressure control valve fitting, (ref# 81). Remove pressure control valve, (ref# 73), from elbow, (ref# 61). Disassemble pressure control valve, by removing valve seat, (ref# 86), from body, (ref# 82). Inspect for and remove foreign material. Inspect ball for wear. Install pressure control repair kit, (ref# 88), if necessary).
4. Piston rod (ref# 93) disconnected from piston (ref# 91). (reconnect piston rod following detailed instructions on page 28-29).


#### **NO PRESSURE, BLUE HYDRAULIC FLUID IN PAINT**

1. Diaphragm broken. (replace with complete diaphragm, (ref# 51). Closely follow detailed instructions on page 26. **NOTE;** If, and only if, paint has contaminated the hydraulic side of the pump, the entire hydraulic system must be cleaned and flushed. Make sure to remove and clean the hydraulic tank screen, (ref# 66), during this process. Refill only with genuine H.E.R.O. LVO hydraulic fluid.  
**NOTE; If lacquer has contaminated the hydraulic system, the piston seal, (ref# 90), must be changed in addition to flushing the system. Closely follow detailed instructions on page 28-29).**

#### **HYDRAULIC SIDE OF PUMP HAS BEEN REPAIRED AND REASSEMBLED, DIAPHRAGM NOT MOVING "PURGING"**

1. Air lock created on hydraulic side of pump. (when the hydraulic side of the pump is working there is no air in it. During repairs it is possible that air has been trapped in the hydraulic system. It must be removed or the pump will not work. To purge the air from the hydraulic system; remove the pressure control knob, (ref# 74), from the valve. Gently pull the P.C. stem, (ref# 77), out. It will pull out about 1/8". Remove the vented hydraulic cap, ref# 68), from the hydraulic tank, (ref# 65), and install accessory pressure cap, item 4-45-3. With a bicycle pump, apply a few pounds of air pressure to the hydraulic tank. This will force the oil through the hydraulic system and push out any of the trapped air. Wait a few minutes. Remove pressure cap and replace with vented cap. Restart the unit and install pressure control knob.  
**NOTE: Unit may be running during purging procedure to speed up the procedure. If a pressure cap is unavailable, simply running the equipment for approximately 5-10 minutes with the P.C. stem pulled out, will purge the system).**

Accessory  
Item  
4-45-3



# TROUBLESHOOTING

## ***SITUATION***

### **POSSIBLE CAUSE (REMEDY)**

#### ***PUDDLE OF OIL APPEARING UNDER SPRAYER DURING OPERATION***

1. Hydraulic fitting loose/cracked or hydraulic lines are punctured. (examine all hydraulic lines and fittings for cracks, breaks or looseness. Replace or tighten as required).
2. Piston seals (ref# 90) worn. (remove and replace piston seals, following closely the detailed instructions on page 28-29).

#### ***CORRECT STATIC PRESSURE, BUT REDUCED SPRAYING PRESSURE***

***(Check with pressure gauge, see page 17 for details).***

1. Spray tip worn out/too large. (replace with new, correct sized spray tip. Tip must not exceed a newer condition .021 tip ).
2. Paint hose incorrect. (replace hose with genuine H.E.R.O. airless spray hose (min. 50 feet). Steel braided hoses must not be used ).
3. Intake valve seat (ref# 12) worn. (replace intake seat closely following detailed instructions on page 23).
4. Intake ball (ref# 13) worn. (replace intake balls when signs of wear, deformation, nicks or cuts are evident. An out of round ball is the sign of a worn intake seat, (ref# 12), and both items should be replaced).
5. Outgo seat (ref# 25) worn. (replace seat).
6. Outgo ball (ref# 26) worn/damaged. (replace outgo ball).
7. Prime valve (ref# 34) bypassing. (start sprayer. With prime valve closed tightly, handle, (ref# 43), turned clockwise fully, check prime valve return hose, (ref# 48), for material bypass. Repair prime valve using, (ref# 47), if material is bypassing.

#### ***LOW STATIC PRESSURE, LOW SPRAY PRESSURE***

***(Check with pressure gauge, see page 17 for details).***

1. Pressure control valve stem screw (ref# 79) loose. (remove pressure control knob, (ref# 74), and inspect screw for looseness. Screw should be secured to stem, (ref# 78), with Loc-Tite. If the screw turns independent of the stem than it must be re-secured. Secure unit so it will not move. Install pressure gauge and .021 spray tip. Obtain a piece of wood, to use as a pusher or purchase a pressure control adjustment tool, 27C-15. Remove pressure control screw and put some Loc-Tite 609 on threads. Turn the screw into the stem a few turns and push it in to its maximum and read pressure. Turn the screw in or out until 3000 psi static pressure is obtained. If you obtain a pressure which higher than 3000 psi, trigger gun to release some pressure and continue adjusting screw until correct pressure is obtained. Let Loc-Tite set up.
2. Pressure control ball (ref# 87) and/or seat (ref# 86) worn. (remove entire pressure control valve, (ref# 73), from sprayer. Remove valve seat, ball, retainer, (ref# 85), and spring, (ref# 84), from valve. Replace with pressure control repair kit, (ref# 88). Hold valve body vertical while placing in spring, followed by retainer. Retainer should be below the valve body (approx. 3/8") when positioned correctly. Center ball on retainer, turn valve seat into body until finger tight, using pipe dope or Teflon tape to seal. Fully tighten using wrench. See page 30.

# TROUBLESHOOTING

## ***SITUATION***

### **POSSIBLE CAUSE (REMEDY)**

#### ***FLUID BEING SPRAYED OUT OF TIP PULSATES, SPRAY HOSE LIES QUIET WHEN GUN TRIGGER CLOSED***

1. Spray tip worn out or too large. (replace with new tip of correct size. Tip must not exceed a good condition .021 tip ).
2. Paint hose incorrect type. (replace with genuine top quality H.E.R.O. airless spray hose. Steel braided hose is not recommended ).
3. Too short a length of hose. (minimum 50' of airless spray hose is required. Replace or add hose until a minimum of 50' is being used).

#### ***FLUID BEING SPRAYED OUT OF TIP PULSATES, SPRAY HOSE CONTINUES TO MOVE VIGOROUSLY WHEN GUN TRIGGER CLOSED***

1. Outgo valve (ref# 22) assembled incorrectly. (remove the outgo valve and reassemble closely following the instructions on page 24).
2. Outgo valve ball (ref# 26) worn out or jammed. (inspect outgo ball to ensure that it is round and free of nicks or cuts. Inspect for foreign material jamming ball. Inspect seat and cage for wear. Replace parts as required).

#### ***PUMP SPRAYS WATER OR SOLVENT AT CORRECT PRESSURES, BUT WILL NOT SPRAY PAINT (Check with pressure gauge, see page 17)***

1. Air leak in paint intake siphon assembly. (check all fittings and hose clamps in intake assembly for tightness).
2. Air leak in paint intake. (check for cracked or broken intake fittings. Swivel connector, (ref# 8), or hose barb, (ref# 7), may be damaged due to over tightening. Look for small black hairline fractures. Replace damaged parts).
3. Partial blockage in paint intake siphon hose, (ref# 5) or siphon screen (ref# 2) (clean and remove any blockages from intake siphon hose or screen. Check to insure strainer bag is not clogging intake siphon hose or screen).

#### ***SPRAYER DOES NOT PRIME WITH PAINT***

1. Heavy bodied paint, pump dry. (refer to " Operating Instructions" and follow priming instructions using the correct thinner for the paint you are to use).

#### ***SPRAYER DOES NOT PRIME WITH CORRECT THINNER***

1. Pump completely dry. (pump may experience difficulty in priming when it is completely dry. First invert siphon tube and pour thinner into siphon tube, to help prime dry pump).
2. Intake siphon assembly (ref# 1) has loose/damaged fittings, loose clamps, or damaged hose. (check all fittings, hose clamps, for tightness, siphon hose for damage or holes. Replace or tighten as required).
3. Intake valve ball (ref# 13) stuck. (remove intake endcap, (ref# 11), and free ball and reassemble).
4. Outgo valve ball (ref# 26) stuck. (remove outgo valve, (ref# 22). Unthread outgo valve upper body, (ref# 29), from outgo body lower, (ref# 23). Remove outgo seat, (ref# 25), from upper body. Free ball and reassemble following detailed instructions on page 24).

# TROUBLESHOOTING

## ***SITUATION***

### **POSSIBLE CAUSE (REMEDY)**

#### ***SPRAY MATERIAL LEAKS AT PRIME VALVE STEM***

1. Prime valve stem packings (ref# 38 or 39) defective. (replace damaged packings following detailed instructions on page 25).

#### ***SPRAY MATERIAL LEAKS OUT PRIME VALVE HOSE WITH VALVE CLOSED***

1. Prime not closed tightly. (tighten valve handle (ref# 43) further)
2. Prime valve worn. ( install prime valve repair kit, (ref# 47). See page 25 for detailed instructions.)

#### ***SPRAY PATTERN IS SPOTTY OR UNEVEN***

1. Pressure is too low. (increase pressure slowly until problem is corrected ).
2. Spray material too thick. (thin as recommended by material manufacturer).
3. Plugged siphon screen, siphon tube, gun filter or a combination. (inspect and clean or replace as required).
4. Plugged tip. (remove and clean tip).
5. Pump malfunctioning or unsuitable for the material. (refer to other areas of troubleshooting guide and check material requirements vs 300S/SL output abilities).

#### ***SPRAY PATTERN LEAVES LINES OR FINGERS***





- 1 Pressure too low. (increase pressure slowly until problem is corrected).
- 2 Worn tip. (replace tip).
- 3 Tip too small for spray material. (change to larger tip or increase pressure. See material manufacturers recommendations).

#### ***EXCESSIVE OVERSPRAY OR FOGGING***

1. Pressure too high. (reduce pressure as required).
2. Material too thin. (follow material manufacturers recommendations re-thinning).
3. Tip too large. (reduce tip size).
4. Improper application technique. (refer to proper application techniques on page 10-11).
5. Too windy. (wait for wind to let up).

## REPLACEMENT OF INTAKE SEAT

<i>Tools or Supplies Required</i>			
◆ 1/4 Allan wrench	◆ 5/8 Socket	◆ Loc-Tite 609	◆ Crescent Wrench
◆ Torque Wrench	◆ Hammer	◆ Lacquer Thinner	◆ Vise – Optional











1. Remove the four bolts (ref# 9), securing the intake endcap (ref# 11) to the pump.
2. Remove the ball cage (ref# 14), ball (ref# 13) and elbow (ref# 8) from the endcap.
3. Place endcap on work bench, with external side facing up.
4. Use socket or screw driver and hammer to gently tap out seat.
5. Remove any Loc-Tite residue from the area from which the seat was removed. Inspect for any signs of wear or erosion in this area. If wear or erosion is found, discard the entire endcap and replace with 4-4B.
6. Use lacquer thinner to clean both the seat and endcap in the area where the seat will be positioned.
7. The fit of the seat to endcap is very tight. To aid in the installation, place the endcap in very hot water and the seat in very cold water. The heat causes the endcap to expand and the cold causes the seat to contract, making installation easier.
8. Dry off seat and endcap.
9. Apply Loc-Tite 609, around the outside of seat and in the machined area where the seat will rest.
10. Slip seat into the endcap. The seat should rest flush with or slightly below the surrounding area, when correctly installed. Use a wooden or nylon dowel to gently tap into place if the seat did not fall into place fully. Use caution as the tungsten carbide seat is very brittle, ( yet strong ) and may chip or break. **NOTE: If the seat will not fit into the endcap using the heating /cooling method;**
  - A. Follow steps 6 & 8.
  - B. Place seat into endcap and put 5/8" socket against seat.
  - C. Place entire assembly into vise, with endcap against one vise jaw and the socket against the other.
  - D. Tighten the vise and it will work as a press to force the seat into the endcap.
11. Use a steel punch and punch four(4) new marks around the newly installed seat. The punch marks help to expand the metal around the seat, giving a firmer grip.
12. Allow the endcap to sit for at least 12 hours while the Loc-Tite cures.
13. Always install a new intake ball (ref# 13) after replacing seat.
14. Install intake cage, ensuring a minimum 1/32" clearance between ball and cage sides.
15. Install intake elbow (ref# 8), ensuring elbow is in line with cage.
16. Install intake valve, using the four bolts removed in step 1.
17. Torque to 30 foot pounds, using criss-cross pattern.

# OUTGO VALVE

<i>Tools or Supplies Required</i>	
◆ Vice	◆ 5/8" Open end wrench
◆ 11/16" Open end wrench	◆ 1" Open end wrench
◆ Teflon Tape or pipe sealant.	

Outgo  
swivel  
ref# 30

- 1 Open prime valve, (ref# 34) in order to release pressure from the material side of pump.
- 2 Remove pressure control knob, (ref# 74) and pull P.C. stem, (ref# 77) out to internal stop, thereby releasing hydraulic pressure.
- 3 Disconnect outgo tee, (ref# 33) from outgo swivel, (ref# 30) on the outgo valve.
- 4 Remove outgo valve from machine by turning counter clockwise.
- 5 Invert valve and secure upper part of valve, (ref# 29) in vise.
- 6 Remove lower half of valve, (ref# 23).
- 7 Remove crush washer, (ref# 24), seat, (ref# 26), ball, (ref# 26), cage, (ref# 27) and spring, (ref# 28). Clean and inspect all parts for wear. Replace any worn parts.
- 8 Apply Teflon tape to threads of outgo upper body.
- 9 Place spring, large end first, into outgo body. Spring should fit into slot machined into tunnel.
- 10 Place cage onto spring, with open end up.  
**NOTE:** Cage should be open so that it drags down the sides of the tunnel during installation. If closed too much it will trap the ball and cause pulsation in spray pattern.
- 11 Place ball into cage.
- 12 Install seat, beveled side down to ball. Seat should fit snugly into outgo body. Press on seat to ensure it will compress until it is flush with outgo body. Release slowly to ensure the parts do not dislodge themselves.
- 13 Place crush washer on seat. Replace crush washer if badly crushed.
- 14 Thread outgo lower onto outgo upper until finger tight. Tighten 1/2 turn with wrench. **NOTE:** *Teflon tape or pipe sealant should be used.*
- 15 Attach repaired valve to machine, installing a new crush washer, (ref# 21) following steps 3-4 in reverse order.




## SPECIAL NOTES:

- ◆ To check the ball for wear, place against a new seat and check sealing edge against a bright light.
- ◆ A used seat may be checked in a similar manner using a new ball. Replace used part if light pass at sealing edge.

## REPAIR OF BLEED VALVE

<i>Tools or Supplies Required</i>		
♦ Vise	♦ 5/8 Open end wrench	♦ 3/4 Open end wrench
♦ 9/16 Open end wrench	♦ Teflon Tape, optional*	♦ Loc-Tite, optional **




### *Bleed Valve Repair Kit Installation*

1. Open bleed valve (ref # 34), turning handle counter-clockwise to release pressure from material side of pump.
2. Remove bleed valve return hose, (ref # 48) from bleed valve return fitting, (ref # 44).
3. Place wrench on bleed valve connector, (ref # 35). Turn counter-clockwise to remove valve from outgo tee, (ref # 33).
4. Secure valve vertically in vise, clamping vise jaws on the flats of valve nut ( ref # 36 ). See picture above.
5. Use wrench to remove valve housing (ref # 41) from nut, (ref # 36).
6. Remove ball, (ref # 37 ), seat, (ref # 26) and crush washer, (ref # 24).
7. Install new crush washer and seat, ( ensuring the beveled surface of seat is facing out ) into the bleed valve nut ( ref # 36 ). Place new ball into bevel of seat.
8. Re-install valve housing ( \* Use of Teflon Tape or pipe sealant is optional ). Tighten 1/4 turn past finger tight. If leakage occurs at this junction point during operation, tighten 1/4 turn more or until leakage stops.
- 9. To install new valve stem, or valve stem seals, (ref # 38 or 39), continue at step 9 .**
10. Complete steps 1 to 5 from above.
11. Place valve housing in vise.
12. Use 1/2" wrench to loosen jam nut ( ref # 42 ), and remove handle.
13. Remove jam nut from valve stem ( ref # 40 ), and unthread valve stem down through housing.
14. Remove existing o-ring and washer ( ref # 38 & 39 ) from stem. Replace with new parts, ensuring they are installed in the correct order on stem. Refer to diagram.
15. Thread stem back into housing until all threads are used. Thread jam nut on to valve stem.
16. Re-assembly valve. Refer to steps 6 to 8 from instructions above.
17. Thread handle onto valve stem. Allow stem to thread down onto ball ( internally ). Tighten handle firmly. Hold handle while tightening jam nut ( Ref # 42 ) tightly against handle. ( \*\* Use of Loc-Tite is optional )

## DIAPHRAGM REPLACEMENT


<i>Tools or Supplies Required</i>			
◆ 1/4 Allan wrench	◆ 4-45-3 Pressure cap	◆ Torque Wrench	◆ 3/8" Open end wrench
◆ 1/8 Allan wrench	◆ H.E.R.O. hydraulic oil	◆ Rags	◆ Drip / collection tray



1. Tilt unit up onto its' nose ( resting vertically on handle, ref# 130). See Fig. 1, page 27.
  2. Remove the eight bolts ( ref# 17) securing the paint head ( ref# 18) to the hydraulic head ( ref# 53).
  3. Remove diaphragm ( ref# 51) from the hydraulic head.
  4. If the diaphragm's metal hubs are rough or sharp, replace with complete diaphragm. Continue at step 11.
  5. If the diaphragm's hubs are smooth and unworn, replace with repair kit ( ref# 52).
  6. Dismantle old diaphragm.
  7. Slide "large" steel hub (A) onto new screw (B) provide in kit. The screw should fit in counter sunk hole, leaving the flat side of hub facing away from screw head.
  8. Thread the small nylon disc (C), diaphragm pad (D) and second small disc (C) onto the screw. There is no correct side to the pads. They **MUST** be threaded on to avoid leakage due to the hole being enlarged.
  9. Slide the smaller hub (E) onto the screw, being certain the beveled edge of the plate is next to the nylon pads. During operation the diaphragm flexes over the beveled edge. If reversed, ( flat edge against diaphragm ) the diaphragm will be cut on the sharp edge while in operation. Thread on and tighten nut (F), supplied in kit. **DO NOT** re-use old nut.
  10. Fill the hydraulic head cavity with genuine H.E.R.O. hydraulic oil, before placing diaphragm onto hydraulic head.
  11. Place new or repair diaphragm onto hydraulic head with the large hub facing up ( Screw head visible ). Ensure diaphragm is centered and within the hydraulic head's recessed area.
  12. Place paint head / endcap assembly onto the hydraulic head. Ensure correct orientation.
  13. Install mounting bolts, and using a criss-cross pattern, tighten bolts to 30 foot pounds.
  14. Purge hydraulic oil system per instructions on page 19.
- ◆ The diaphragm will take on a wrinkled or puckered appearance almost immediately after operation begins. Do Not be concerned by this. A diaphragm requires replacement when hydraulic oil appears in the spray material. Annual replacement of the diaphragm is recommended as part of your preventive maintenance procedures.

# HYDRAULIC HEAD INSERT REPLACEMENT



<i>Tools or Supplies Required</i>			
◆ 1/4 Allan wrench	◆ 4-45-3 Pressure cap	◆ Torque Wrench	◆ 17S Balls ( 2 ) Slightly used. May damage new.
◆ Vise	◆ H.E.R.O. hydraulic oil	◆ Rags	



1. Tilt unit up onto its' nose ( resting vertically on handle, ref# 130). See Fig. 1.
  2. Remove the eight bolts ( ref# 17) securing the paint head ( ref# 18) to the hydraulic head ( ref# 53).
  3. Place rags around the cylinder area to absorb hydraulic oil which will leak while performing step 4.
  4. Remove the six bolts ( ref# 59 ) securing the crossblock/cylinder/hydraulic head. Bolts are accessed from the underside of crossblock.
  5. Remove hydraulic head ( ref# 53) to work bench.
  6. Remove old, broken or damaged insert ( ref# 55).
- NOTE: Insert should have no movement, when properly installed. If it is spinning or able to move back and forth, but has not come completely free of the hydraulic head, it may be possible to re-tighten using the same installation instructions to follow. See steps 8 – 10.**
7. Place new insert into the hydraulic head. See fig. 2. Insert will protrude through the hydraulic head by approximately 1/8". To affix the insert the extra material of the insert must be flared to secure to the hydraulic head.
  8. Position a steel ball on the front and back of the insert. See figure 3.
  9. Position this assembly in the jaws of a vise.
  10. Slowly close the vise jaws. The vise acts as a press and the ball will cause the extra insert material to flair around the head. Continue closing vise until the insert is tight and can no longer be rotated or spin in the hydraulic head. Over tightening can create cracks or splits in the flange/flare, leading to repeat failures. Do Not over tighten.
  11. Re-assemble pump, in the reverse order of removal. Torque all bolts to 30 foot pounds.
  12. Once the repairs are completed , return unit to horizontal position, replenish lost oil and purge per instructions on page 19.

## PISTON REPAIRS

<i>Tools or Supplies Required</i>		
♦ Vise	♦ Golf tee	♦ Grease
♦ 9/16 Open end wrench	♦ Pick or dental tool.	♦ H.E.R.O. hydraulic oil.
♦ 1/2 Socket	♦ Torque Wrench	♦ 4-45-3 Pressure cap
♦ Circlip pliers	♦	♦




1. Remove hydraulic feed line, (ref# 63) from hydraulic intake valve, (ref# 62) and also remove hydraulic return line, (ref# 72) from the pressure control valve, (ref# 73). Plug lines to minimize oil loss. (Hint; golf tees work well for this)
2. Remove the bolts, (ref# 114) passing through the side frames, (ref# 110,111), into the crossblock, (ref# 60).
3. Place a drain tray under cylinder area.
4. Grasp the pump assembly, and pull away from the piston. Stop when piston pulls free, to allow the hydraulic oil to drain into pan. Completely remove pump assembly from between side frames.
5. If only replacing piston seals, (ref# 90) continue at step 15.
6. Remove the piston, (ref# 89) from eccentric bearing, (ref# 98). Move to clean work bench for repairs.

## PISTON REPAIRS

7. Remove piston circlip, using circlip pliers. Remove piston from rod.  
**NOTE:** *Use extreme caution not to damage circlip or the internal circlip groove of piston. Piston rod circlip, washer, o-ring, and nut are not available individually. Parts are available with the purchase of piston rod, (ref# 93) only. The circlip will have one sharp edge and one smooth edge. The smooth edge should be towards the washer. If reversed, the rod will continually pull out of the piston.*
8. Remove bronze piston rod seat, (ref# 92) from piston, (ref# 91).
9. Examine all parts for wear or damage. Replace as required.
10. Fill the center cavity of piston rod seat until flush with grease. Slide seat into piston with concave side (filled with grease) facing out.
11. Lightly grease the ball end of piston rod. Push piston rod into piston until ball end of rod contacts seat.
12. Slide o-ring and steel washer down rod and into piston. Slide circlip down into piston and snap into the internal circlip groove of piston using circlip pliers.  
**NOTE:** Circlip must fully expand into groove of piston. Circlip has fully expanded when there is 13/64" space between circlip eyelets.  
12.**NOTE:** If you experience difficulty installing circlip, remove a small quantity of grease. When installed correctly, rod should move slowly and without any free play.
13. If piston seals, (ref# 90) are required, they may be installed now or after piston has been re-attached.
14. Thread rod into eccentric bearing holder, (ref# 98) until nut is flush with eccentric bearing. Tighten snugly.  
**NOTE:** *Piston rod nut must remain fully threaded onto rod, if during installation, the nut begins to loosen from rod, re-tighten to rod. Place vise grips on rod to assist in tightening piston rod into eccentric.*
15. Remove and discard old piston seals.
16. Piston seal kits, (ref# 90) contain a total of four pieces (1 o-ring, 1 flat washer, 2 cup washers). Take note of their installation sequence by referring to drawing. The piston has three machined grooves, which have been marked on the drawing as A, B, & C.
17. Place flat washer (one side has a contoured face) into groove "C", then place o-ring in front of flat washer, so that it fits into the contoured face of the flat washer.
18. Place one cup washer into groove "B", with open face of cup washer facing the end of piston. (towards hydraulic oil when installed)
19. Place second cup washer into groove "A".  
**NOTE:** *Always work from the front of the piston back so that you are always moving the cup washers over filled grooves. This avoids damage that can occur to the cup washers if they have to be dug out of one groove and moved to another. Avoid over stretching.*  
**NOTE:** *A small, dental like tool, may be used to assist in moving cup washers.*
20. Apply grease to seals before installing in cylinder, (ref# 57).
21. Slide pump assembly into side frames and guide piston into cylinder  
**NOTE:** *Use care not to push the piston too far into cylinder. If piston rings slide in too far they will pass through cylinder into the hydraulic cavity. Complete dismantling of piston will be required to remove. The piston can not be pulled back if the seals have gone through cylinder.*
22. Reattach crossblock bolts, as removed in step 2. Torque bolts to 30 foot pounds.
23. Reconnect hydraulic lines, as removed in step 1.
24. Add new hydraulic oil to hydraulic tank, using only genuine H.E.R.O. LVO hydraulic oil.
25. Once the repairs have been completed, the hydraulic oil will require purging to remove the trapped air. See "**PURGING**" instructions on page 19.

## PRESSURE CONTROL VALVE



<i>Tools or Supplies Required</i>		
◆ Vise	◆ 11/16" Open end wrench	◆ H.E.R.O. hydraulic oil
◆ 7/16" Open end wrench	◆ 1" Open end wrench	◆ 4-45-3 Pressure cap
◆ Teflon Tape or pipe sealant, optional *		

- 1 Remove pressure control knob, (ref# 74) and pull P.C. stem, (ref# 77) out to the internal stop (1/16" to 1/8") thereby releasing hydraulic pressure.
- 2 Remove hydraulic return line, (ref# 72) from P.C. fitting, (ref# 81).
- 3 Place 11/16" wrench on P.C. seat, (ref# 87). Turn counter-clockwise to remove complete valve.
- 4 Place complete valve in vise and remove seat from body, (ref# 81).
- 5 Remove ball, (ref# 86), retainer, (ref# 85), and spring, (ref# 84) from body. Inspect ball for nicks or cuts and replace if damaged. Inspect seat at sealing edge, for signs of wear. A good condition seat will have a very small beveled at the sealing edge. The larger the bevel the more wear has taken place. Inspect retainer for wear. The retainer has a small locating hole in it. The hole should be flush or slightly beveled. The greater the wear on the ball, seat, and retainer the poorer the static pressure will be. Replace parts individually, or use repair kit, (ref# 88).
- 6 Hold P.C. body vertical. Place spring into body, place retainer onto spring. Ensure retainer fits completely over spring. Retainer should rest below end of body by approximately 1/4" to 3/8". Place ball onto retainer, ensuring ball is located on center hole.
- 7 Thread on seat, using care not to dislodge the ball from its position on the retainer. Tighten firmly.
- 8 Apply pipe dope or Teflon tape to exterior threads of seat. Install into elbow. Tighten to prevent leaks and return to original position.
- 9 Reattach hydraulic line. See "**PURGING**" instructions on page 19.

## ACCESSORIES

1/4x1/4	Hose to Hose Connector
114	Paint Hose, 50' x 1/4"
3-Whipend	Whipend, 3' x 3/16"
10-55-011-2	ASM Gun, Model 400, 2 Finger Trigger, c/w 1710 Zip Tip
10-55-011-4	ASM Gun, Model 400, 4 Finger Trigger, c/w 1710 Zip Tip
10-55-300-2	ASM Gun, Model 300, 2 Finger Trigger, c/w 1710 Zip Tip
10-55-300-4	ASM Gun, Model 300, 4 Finger Trigger, c/w 1710 Zip Tip
5GAL SB-25	Strainer Bags, 5 Gallon, 25 per Carton
4-649	Wonder Wash, 1.5 ounce, 48 per Carton
4-655	Wonder Wash, 5 ounce, 25 per Carton
4-660	Wonder Wash, 5 lbs. Bulk
4-662	Wonder Coat, 1 Liter Bottle
4-664	Wonder Coat, 12 x 4-662 Carton
661	Spray Trigger, for use with 4-662
4-666	Wonder Coat, 4 Liter Bottle ( Refill )
4-LVO-1	Hydraulic Oil ( LVO ), 1 Liter Bottle
4-LV0-4	Hydraulic Oil ( LVO ), 4 Liter Bottle
4-67/19	Pressure Gauge, c/w Mounting Tee
4-45-3	Pressure Cap
10-QRP-3	Quick Reach Extension Pole, 3 Feet
10-QRP-5	Quick Reach Extension Pole, 5 Feet
10-QRP-8	Quick Reach Extension Pole, 8 Feet
BB-010	"Bucket Buster" Plastic Pail Opener

## PARTS LIST

Please order parts by the appropriate part number and not by reference number.  
The quantity required, per unit, is shown for each part number. Part numbers in **bold** text indicate whole assemblies or kits. These parts may also be purchased individually

### INTAKE PARTS

REF	PART #	DESCRIPTION	QTY
1	<b>4-210</b>	<b>SIPHON ASSEMBLY COMPLETE, ( Ref# 2-7, 48-50 )</b>	<b>ASSY</b>
2	187A	SCREEN, Siphon, Coarse, Includes	1
3		<i>Not Used</i>	
4	189A-1	TUBE, Siphon, Metal, 5 Gal.	1
5	4-184A	HOSE, Siphon, 21"L x 3/4" ID, Lacquer Resistant	1
6	1/75-3	CLAMP	2
7	667-27	BARB, Hose to Elbow, 3/4"	1
8	667-26	ELBOW, 3/4"	1
9	3B	CAPSCREW, SKT HD 3/8NC x 2", Gr. 8	4
10	3-2	WASHER, 3/8" Hi Collar Lock	4
11	4-4B	ENDCAP, Includes ref# 12	<b>ASSY</b>
12	6	SEAT, 3/4" Tungsten Carbide	1
13	17S	BALL, 3/4", Steel, Corrosion Resistant, <i>Use with spring cage ( 4-183S )</i>	1
14	4-183S	CAGE, Spring Loaded, <i>Use with steel ball ( 17S )</i>	1
15	19A	SPRING	1
16	5V	O-RING, Viton	1
17	3	CAPSCREW, SKT HD, 5/16 x 1-3/4"	8
18	21E	HEAD, Material / Paint	1
19	4-6652	REPAIR KIT ( Ref# 13 (2), 14-16 )	<b>KIT</b>
20	4-6653	OVERHAUL KIT ( Ref# 12, 13 (2), 14-16 )	<b>KIT</b>

### OUTGO PARTS

21	7C	WASHER, Copper Crush	1
22	<b>4-11A</b>	<b>OUTGO VALVE COMPLETE, ( Ref# 23-30)</b>	<b>ASSY</b>
23	11A-1	LOWER, Valve Body	1
24	11A-3CP	WASHER, Copper Crush	1
25	11A-4	SEAT, 3/8, Tungsten Carbide	1
26	11A-5	BALL, NYLON, 3/8	1
27	11A-6	CAGE	1
28	11A-7	SPRING	1
29	11A-2	UPPER, Valve Body,	1

## PARTS LIST

Please order parts by the appropriate part number and not by reference number.  
The quantity required, per unit, is shown for each part number. Part numbers in **bold** text indicate whole assemblies or kits. These parts may also be purchased individually

### OUTGO PARTS

REF	PART #	DESCRIPTION	QTY
30	20	SWIVEL	1
31	4-6654	REPAIR KIT ( ref# 21, 24, 26(2), 27-28 )	KIT
32	4-6655	OVERHAUL KIT ( ref# 21, 24, 25, 26(2), 27-28 )	KIT
33	13-1	TEE, Female x Male x Male	1
<b>34</b>	<b>4-606</b>	<b>BLEED VALVE COMPLETE ( Ref# 35-46 )</b>	<b>ASSY</b>
35	14A	CONNECTOR, 1/4 x 1/4	2
36	606-2	NUT, Bleed Valve	1
37	11A-5	Ball, 3/8, Steel	1
38	606-8	O-RING, Bleed Valve, Stem	1
39	606-15	WASHER, Back – Up	1
40	606-10	STEM, Bleed Valve	1
41	606-1	HOUSING, Bleed Valve	1
42	HW4053	JAM NUT, 3/8 NC	1
43	4-606-9	HANDLE, T, Complete with pin	1
44	603-6	BARB, Hose	1
45	603-12	DECAL, Bleed Valve “Close Tightly After Prime”	1
46	606-12	LABEL, Bleed Valve “Max WPR 4000 PSI”	1
<b>47</b>	<b>4-606RK</b>	<b>REPAIR KIT, Bleed Valve ( Ref# 24, 25, 37 )</b>	<b>KIT</b>
48	4-185B	HOSE, P.V. Return Line	1
49	196	CLAMP	1
50	188	TIES	2

### HYDRAULIC PARTS

51	<b>4-22C</b>	<b>DIAPHRAGM ASSEMBLY</b>	<b>1</b>
52	4-22CRK	REPAIR KIT, Diaphragm ( Diaphragm less steel plates )	KIT
53	4-23A-2	HEAD ASSEMBLY, complete with insert. ( ref# 54-55 )	ASSY
54	4-23A	HEAD, Hydraulic.	1
55	23A-1	INSERT, Head, 3/4” cylinders only	1
56	5	O-RING	1
57	24/75	CYLINDER, 3/4"	1
58	HW5050P	WASHER, 5/16" SAE, Plated	6
59	36	CAPSCREW, SKT. HD., 5/16NC x 2-3/4"	6

## PARTS LIST

Please order parts by the appropriate part number and not by reference number.  
The quantity required, per unit, is shown for each part number. Part numbers in **bold** text indicate whole assemblies or kits. These parts may also be purchased individually

### HYDRAULIC PARTS

REF	PART #	DESCRIPTION	QTY
60	35A	CROSSBLOCK, Aluminum	1
61	25-2	ELBOW	3
62	4-30	VACUUM VALVE	1
63	4-31	FEED LINE, LVO, C/W Fittings, Includes ref# 64	1
64	31-1	ORIFICE, Metering	1
<b>65</b>	<b>4-45A</b>	<b>TANK, Complete With Fittings, (ref# 66-68)</b>	<b>ASSY</b>
66	4-45-1	SCREEN, Tank	1
67	45-4	ELBOW, Return	1
68	4-45-2	LID, Vented, Hydraulic Tank	1
69	45B	BRACKET, Tank	1
70	HW1010P	CAPSCREW, HX HD, 1/4NC x 1/2	2
71	45C	STRAP	2
72	4-28	RETURN LINE, LVO, C/W Fittings	1
<b>73</b>	<b>4-27C</b>	<b>PRESSURE CONTROL VALVE, Complete ( Ref# 74-87 )</b>	<b>ASSY</b>
<b>74</b>	<b>4-27C-7</b>	<b>KNOB, P.C., Includes Ref# 75</b>	<b>ASSY</b>
75	HW2010	SETSCREW, SKT. HD. 5/16 NC x 5/16"	1
76	27C-6	LOCK NUT, Aluminum, P.C.	1
<b>77</b>	<b>4-27C-10</b>	<b>STEM ASSEMBLY ( Ref# 78-80 )</b>	<b>ASSY</b>
78	27C-10A	STEM, P.C.	1
79	27C-10B	SCREW, Stem, P.C.	1
80	27C-12	O-RING, P.C.	2
81	4-27C-11	FITTING, Oil Return, P.C.	1
82	27C-8	BODY, P.C.	1
83	27C-9	CIRCLIP, P.C.	1
84	27C-5	SPRING, P.C.	1
85	27C-4	RETAINER, P.C.	1
86	27C-3	SEAT, 38-40RC, P.C.	1
87	27C-2	BALL, Steel	1
<b>88</b>	<b>4-27CRK</b>	<b>REPAIR KIT, Ref# 84-87</b>	<b>KIT</b>
<b>89</b>	<b>4-38A/75</b>	<b>PISTON &amp; ROD ASSEMBLY, 3/4" ( Ref# 90-93 )</b>	<b>ASSY</b>
90	4-37A/75	SEAL SET, Piston, 3/4"	1
91	4-38A/75-1	PISTON, Only, W/O Seals, 3/4"	1

## PARTS LIST

Please order parts by the appropriate part number and not by reference number.  
The quantity required, per unit, is shown for each part number. Part numbers in **bold** text indicate whole assemblies or kits. These parts may also be purchased individually

### HYDRAULIC PARTS

REF	PART #	DESCRIPTION	QTY
92	38A-3	SEAT, Piston, Bronze	1
93	4-38A-2	ROD, Piston, C/W Nut, Washer, O-Ring, Circlip	1

### DRIVE PARTS

94	05-80-5000	BEARING, Crankshaft Side	2
95	HW1055	LT. CARRIAGE, 5/16NC x 5/8"	4
96	HW5060P	WASHER, Lock, 5/16	4
97	HW4030P	NUT, HX. HD, 5/16	4
<b>98</b>	<b>4-39</b>	<b>ECCENTRIC BEARING &amp; HOLDER, C/W Zerk, Ref# 99,100</b>	<b>ASSY</b>
99	39-2	BEARING, Eccentric, Outer	1
100	4-39-3	Holder, Eccentric, C/W Zerk	1
<b>101</b>	<b>4-41</b>	<b>CRANKSHAFT, Includes Ref# 102</b>	<b>ASSY</b>
102	39-1	RACE, Eccentric, Inner	1
<b>103</b>	<b>4-46</b>	<b>KEEPER PLATES, with hardware</b>	<b>ASSY</b>
104	4-49	KEYSTOCK, 3/16 SQ x 1.5"	2
105	4-65/100	SHEAVE, Pump, C/W Set Screws (2), ref# 105	1
106	HW2020	SET SCREW, SKT. HD., 5/16 NC x 7/16	2
107	66/100	BELT	1
108	4-48/100	SHEAVE, Motor, C/W Set Screws ( See Ref# 105 )	1
109	4-61/74	MOTOR, 1.0 H.P., Doerr Motor, Includes Switch, Cord.	1
	65/101M	SWITCH, On/Off, Doerr Motors, Push on Connectors	
	61/105	FAN, Doerr Motors	
	61/106	CLIP, Fan, Doerr Motors	
	61/107	COVER, Fan, Doerr Motors	

### CHASSIS PARTS

110	4-53	FRAME, Left Side	1
111	4-52	FRAME, Right Side	1
112	58	BRACKET, Motor Cord Wrap	2
113	HW5050P	WASHER, 5/16 SAE	6
114	HW1050P	CAPSCREW, HX. HD., 5/16NC x 1/2"	6
115	4-51	ROD, C/W Clips ( Includes Ref# 116 )	1

## PARTS LIST

Please order parts by the appropriate part number and not by reference number.  
The quantity required, per unit, is shown for each part number. Part numbers in **bold** text indicate whole assemblies or kits. These parts may also be purchased individually

### CHASSIS PARTS

REF	PART #	DESCRIPTION	QTY
116	59	E-CLIP	2
117	4-50	BRACKET, Motor Mounting, Includes Ref# 118-119	1
118	HW1070F	CAPSCREW, HX. HD., 5/16NC x 1-1/4", Gr. 5, Full Thread	2
119	HW4040	NUT, Hex Jam, 5/16"	2
120	4-67/13B	LEG	1
121	4-67/14	FOOT PAD, c/w ref# 124, 125	2
122	HW1020P	CAPSCREW, HX HD, 1/4NC x 3/4, PLATED	
123	HW5030P	WASHER, 1/4 SAE, PLATED	
124	HW5040P	WASHER, 1/4 Regular Lock, PLATED	
125	HW4020P	NUT, 1/4NC HX, PLATED	
126	4-66/12-1	BELTGUARD ASSEMBLY, c/w ref# 127 & 128, BLACK	ASSY
127	66/10-1	BELTGUARD, BLACK	1
128	66/10BM-1	FINGER GUARD	1
129	HW1010P	CAPSCREW HX HD, 1/4NC x 1/2, PLATED	2
130	4-1/75-3	FRAME HANDLE	1
131	67/16A	WHEEL, 8 1/4"	2
132	67/17	COTTER PIN	2


### 300S ONLY CHASSIS PARTS

133	210-1	AXLE	1
134	67/12	HANDLE GRIP	1
135	211	HANDLE	1
136	212	SPRING CLIP	1
137	213	PIN	1
138	HW1092P	CAPSCREW, HHCS, 7/16NC x 2-1/4, PLATED	1
139	HW5072P	WASHER, 7/16, L9 TENSION	1
140	HW4062P	NUT, STOVER, 7/16	1
141	HW4060P	NUT, 7/16NC HSF	1
142	214	SIPHON HOLDER	1


### 300SL ONLY CHASSIS PARTS

143	2/78	HANDLE, SNAP ON	1
144	198	AXLE	1

# PARTS SCHEMATIC 300S / 300SL LEGEND



# PARTS SCHEMATIC 300S / 300SL LEGEND



# 300S / 300SI LEGEND

*Manufactured by:*  
H.E.R.O. INDUSTRIES  
2719 LAKE CITY WAY  
BURNABY, B.C.  
CANADA

Phone: 604-420-6543  
800-494-4376  
Fax: 604-420-8725

*Purchased From*

---

---

---

---

Model: \_\_\_\_\_

Serial #: \_\_\_\_\_

Date of Purchase:

---